

USER MANUAL

65” 4K Interactive Flat Panel Display

Vidi-Touch Navigator version



Rev.12/07/2016

NOTICES

COPYRIGHT AND TRADEMARKS

Copyright © 2017 Vidistri Europe BV. All rights reserved.

All brand names and product names are trademarks, registered trademarks or trade names of their respective holders.

General

Every effort has been made to ensure accuracy, however in some cases changes in the products or availability could occur which may not be reflected in this document. We reserve the right to make changes to specifications at any time without notice. Performance specifications are typical, but may vary depending on conditions beyond our control such as maintenance of the product in proper working conditions. Performance specifications are based on information available at the time of printing. We makes no warranty of any kind with regard to this material, including, but not limited to, implied warranties of fitness for a particular purpose. We will not be liable for errors contained herein or for incidental or consequential damages in connection with the performance or use of this material. Our manufacturing facility is ISO 9001 and 14001 certified.

REGULATORY

The product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part of KC,CE, CB,FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the product is operated in a commercial environment. The product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of the product in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's own expense.

Environmental

The product is designed and manufactured with high-quality materials and components that can be recycled and reused. This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from regular waste. Please dispose of the product appropriately and according to local regulations. In the European Union, there are separate collection systems for used electrical and electronic products. Please help us to conserve the environment we live in!

Table of Contents

1	BEFORE USING THE PRODUCT	4
1.1	Safety Precautions	4
2	PREPARATIONS	11
2.1	Parts List	11
2.2	Control product	11
2.3	Input/output connection	13
2.4	Remote Controller Button Description	14
3	INSTALLATION GUIDE	15
3.1	Caution before installation	15
3.2	Unpacking Process	16
3.3	Handling Guide	17
3.4	Product Installation	19
3.5	Wall mounting Installation	19
3.6	Remote Controller	20
3.7	Setup	20
4	REMOTE CONTROL FOR 4K	21
4.1	RS-232C connection	21
5	CONNECT THE EXTERNAL DEVICE	23
5.1	HDMI Connection	23
5.2	VGA Connection	23
6	TOUCH REQUIREMENTS	25
6.1	Touch Requirements	25
7	MENU CONTROL	26
7.1	Input selection	26
7.2	User function	27
8	TROUBLE SHOOTING	28
9	PRODUCT SPECIFICATION	31
10	SUPPORTED RESOLUTIONS	32
11	REQUIRED INFORMATION	33
11.1	Prevent image sticking	33

1 Before using the product

- Before installing or using the product, to avoid damaging the product, read and follow as the guidelines of the user manual for your safety.
- The color, design and specification may change without notice to enhance the function.

1.1 Safety Precautions

Precautions are divided into two "Warning" and "Caution", and meaning of the each is as follows.



Warning: If you do not follow, it could result in serious injury or death.



Caution: If you do not follow, it could result in minor injury or product damage.

Please keep users to access **USER MANUAL** easily.



This illustration below is for reference only.



Warning



Do not use a damaged power cable or plug which does not meet the standard.
- This may cause a fire or an electric shock.



If you are using a power strip, do not use several devices at the same time.
- Due to the heat generated by the multi-outlet, it may cause fire.



Do not touch the power plug with wet hands.
- This may cause an electric shock.



Plug in the outlet end exactly.
- If the connection is not stable, it may cause fire.



Connect the power cable to a grounded outlet.
- This can cause electric shock when the ground is broken or shorted.
- When installing on a place that cannot be grounded, connect to the outlet by using a circuit breaker to protect the product from electric shock.



Do not pull or bend the power cable forcibly.
Avoid placing heavy objects on the cables.
- If the cable is damaged, it may result in electric shock or a fire.



Do not use the power cable near heating appliances and products.
- This may cause a fire or electric shock.



In case of contamination around the power plug or outlet, wipe clean with a dry cloth.
- This may cause a fire.



Do not place flammable objects near the product.
- This may cause a fire.



If you want to install by using the wall mount, make the product be installed by a trained technician. Refer to the User Guide Wall Mounting.
- This may cause injury.



Do not install the product in poorly ventilated places such as a bookshelf or closet.
- Otherwise it may affect internal temperature to be increased and cause a fire.




Install the product at least 10 cm far from the wall.
- Otherwise it may affect internal temperature to be increased and cause a fire.




After unpacking the product, packaging vinyl should be kept away from the hands of young children.
- If a child uses it incorrectly, it may cause a choking accident.



Do not install in locations where has vibration or in an unstable position.
- Product fall may occur and it might cause damage.
- This may cause a fire.



Do not install in places which dirt, moisture, smoke, much water or rain water can reach.
Do not install under the air conditioner that could fall water drops.
- This may result in electric shock or fire.



Avoid exposure to direct sunlight and do not place near hot objects such as a fire or heater heat.
- This may cause a fire or shortening the product life.




Do not install in the low place where a child can touch.
- A child may be injured while playing and touching the product.



Do not install near any kitchen or kitchen counter because it may cause damage or deformation of the product by the vapor or oil.
- This may cause a fire.



Do not try to repair or transform the product because the high voltage can flow inside the product.
- This may cause a fire or electric shock.
- When problem is found in the product, contact a service center.



Do not use electrical equipment which uses high-voltage around the product.
- This may result in poor quality of display or cause amblyopia.
- This may cause a fire or electric shock.



When moving the product, turn off the power and remove all of the cables including power cables connected to the product.
- If the cable is damaged, it may cause a fire or electric shock.



When smelling something burning or hearing strange sound from the product, disconnect the power cable immediately and contact a service center.
- This may cause a fire or electric shock.



Do not allow a child to get on or hang on the product.
- If the product falls off, a child may result in injury or death.



Do not place heavy object, toy or sweets that a child can play with on the product.
- If a child hangs the product and fall, it may cause personal injury or death.



When the product is damaged or falls off, disconnect the power cable immediately and contact a service center.
- This may cause a fire or electric shock.



When lightning occurs, turn off the power switch and disconnect the power cable.
- This may cause a fire or electric shock.



Do not drop the product or throw something to the product.
- This may cause a fire or electric shock.



Do not give a shock or scratch to the screen with sharp objects.
- This may cause damage to the product.



Do not pull the power cable or signal cables connected to the product when moving the product.
- Cable damage may cause a malfunction or an electric shock or fire.



Do not shake or uplift a product by holding only the power cable and signal cable.
- Cable damage may cause a malfunction or an electric shock or fire.



If you smell a gas around the place of the product or there is a risk of a gas leakage,
Do not plug in or turn on the product. Make sure to ventilate.
- A spark in the appliance power can cause an explosion or fire.



Do not store or use flammable material and flammable sprays near the product.
- This may cause an explosion or fire.



Please do not block a vent with the curtain or cloth, etc.
- The rise of internal temperature may cause a fire.



Do not put a steel rod, coin, hair pin etc. in the vent and input/output terminals of the product.
Also, do not put a flammable object such as papers.
- When a strange substance enters into the product, turn off the power of the product. Please contact the Service Center after unplugging the power cable.
- This may cause a malfunction or an electric shock or fire.



Do not place anything containing liquid or metals on the product.
- When a strange substance enters into the product, turn off the power of the product. Please contact the Service Center after unplugging the power cable.
- This may cause a malfunction or an electric shock or fire.

Caution



Do not unplug the power cable while using the product.
- This may cause a fire or electric shock.



Use only the power cable qualified for the standard.
- This may cause a fire or electric shock.




Connect the power cable to the nearest outlet.
- If having a problem with the product, unplug the power cable completely.



When disconnecting the power cable from the outlet, do not pull the cable wire.
Please be sure to hold the plug and separate it.
- This may cause a fire or electric shock.



Please move the product carefully not to occur the twist and drop.
- This may cause a malfunction or injury.



Put the product's screen faces upwards.
- The screen may be damaged.



Work together more than one person if the product is heavy.
- This may cause a malfunction or injury.



When installing the product on a cabinet or shelf, use the larger size of the tray
than the product to use and maintain the horizon.
- The product may fall and cause damage or injury.



Please do not shock when installing the product.
- This may cause a malfunction.



When installing the product in a special place, contact a dealer or a service center
because the peculiar environment can be effected to the event of a problem with
the
- This may cause a malfunction or fire.




Turning on the product in the condition of the fixed screen or 4:3 screen for a long time may also cause an afterimage or stain on the screen.

- When using the product for a long time, set a screen saver of the connected computer or signaling equipment products or set it in sleep mode.



When you are not using the product for a long time, after unplugging the power cable and take action to prevent the product from a dust.

- Dust accumulation, heat generation or sparks can occur and cause fire.




Set a resolution and frequency appropriately to the product.

- The state of the screen can result in poor or blurred vision.



For products with a stand, do not move the product by holding only the stand or lift the product upside down.

- The stand might be split from the product and it may cause damage or injury.




Look at the screen from a distance of about longer 2.5 times than the screen diagonal length.

- Looking at the screen for a long time can lead to vision loss.



Do not use anything that causes the water vapor near the product. (Moisturizers, etc.).

- This may cause a malfunction or an electric shock or fire.




After 1 hours use, rest your eyes for more than 5 minutes.



If the product is turned on for a long time, do not touch the screen surface or vent because it may be hot.



Keep the accessories of the products out of reach of children.




For products with a stand, be careful when adjusting the angle and height of the stand of the product.


- Tilting severely the product may cause the product to fall off and injury.
- Stuck a finger or hand may cause an injury.



Do not place heavy objects on the product.
- This may result in a malfunction or an injury.



Please put obstacles away from the space between the remote controller and the product.
- The product may not be operated by remote controller.



The remote control may not be good in this operation under the sun or strong light.
Please change the location of the product in this case.



Make sure that a child does not eat the battery and keep it out of a child's reach.
- If a child eats the battery, please consult a doctor immediately.



When replacing the battery, insert it to the correct polarities (+, -).
- If it is different from the polarity of the battery, it may cause a fire or injury to break or leak.
- This may also contaminate the surrounding.



Use a standard battery; do not mix old batteries with new one.
- If it is different from the polarity of the battery, it may cause a fire or injury to break or leak.
- This may also contaminate the surrounding.



The depleted Battery and rechargeable batteries must be handled separately from the general waste and it needs to be collected for recycling.
- If the end-of-life battery, please bring your nearest recycling center or battery dealer
- This may cause an explosion or fire.

Cleaning



After disconnecting the power cable, wipe contaminated parts and each part of the product screen lightly with a dry and soft cloth.

Do not clean the product directly with a wet cloth or wet spray water.
- There is a risk of fire or an electric shock.

When washing by various cleaning agents, brighteners, abrasives, waxes, benzene, alcohol, solvent, surface active agent, the surface of the product may be damaged.



If cleaning inside the product is required, please contact your dealer or service center.
- This may result in fire or electric shock.

2 Preparations

2.1 Parts List



If these items are missing, contact your dealer or service center.



The following images may differ from the image shown.



Other parts not packed in contents may cause performance degradation or problem during use.



HDMI Cable



Power Cable
(Option)



Remote
Control



AAA 1.5V
Battery x 2



Touch USB Cable
& Extension cable



IFPD touch pen




Cleaning cloth

2.2 Control product

 The following images may differ from the image shown.

- You can control the product by using the control buttons on the rear side of the product.



*Hotkey is optional

Remote Sensor / Power indicator - ①


Power on	Green
Stand-by	Red
Power Saving (on)	Red
Power Saving (Backlight)	Green

Control buttons – ②

Vol+	To turn up the volume.
Vol-	To turn down the volume
Up	To move to the upper menu or select
Down	To move to the lower menu
Source	To display input signal
Menu	To display or hide the on-screen menu
Power	Power on/off button

2.3 Input/output connection

 The items may differ from the image shown (AD board:AD51UN).



Connector name and description

No.	Connector	Description
①	Fan on/off	To on/off fan switch
②	Touch USB(PC)	To connect Touch USB(PC)
③	Touch USB(LAPTOP)	To connect Touch USB(LAPTOP) - Priority
④	Speaker Out	To connect External Speaker
⑤	RS232	To connect RS232 input cable with control device (D-sub 9pin)
⑥	HDMI 3 / MHL3.0	To connect HDMI 1.4/2.0(MHL 3.0) video & audio input – 3
⑦	HDMI 2	To connect HDMI 1.4/2.0 video & audio input – 2
⑧	HDMI 1	To connect HDMI 1.4/2.0 video & audio input – 1
⑨	USB	To connect with USB device
⑩	D-SUB	To connect D-sub 15pin
⑪	Sound	To connect audio input (3.5Φ)
⑫	AV	To connect AV for CVBS, L/R
⑬	Component	To connect component for Y, PB, PR
⑭	S/PDIF	To connect SPDIF
⑮	Earphone	To connect audio output (it will be removed.)
⑯	AC 100-240V 50/60Hz	Power connector (AC 100-240V, 50/60Hz)

USB Multi media playback format

Media	File Ext.	Decoder	Notes
Music	.mp3	.mp3	Sample Rate: 8K~48KHz Bit Rate: [kbit/s] 32~320K
Photo	.jpg/.jpe eg	.jpg	Max Resolution: 15360x8640,Min100x100
		.jpe	Max Resolution: 15360x8640,Min100x100

Caution

- When you connect the signal cables to the input / output terminals, check the above picture of the input / output terminal, and connect in the right direction. If connected incorrectly, it may cause damage or breakdown of the input / output terminals.
- If the product does not operate even though the power is supplied, check if the power switch is set to power-on or not.

2.4

Remote Controller Button Description

Button Description



The following images may differ from the actual items.



Button not described does not work.

POWER	Power on/off button
SOURCE	Select input signal
ASPECT	Adjust the window's ratio
	Move to the upper menu
	Move to the lower menu
◀	Move to the left menu
▶	Move to the right menu
OK	Select to change menu
MENU	Display or hide menu on the screen
+	Volume up
-	Volume down



3 Installation Guide

3.1 Caution before installation

 **Caution:** Installation must be performed by a qualified custom video installation specialist under the conditional installation environment as below.

Ambient Lighting

- When the sun or strong light shines on the front screen of the product, image contrast can be seen as it is decreased conspicuously or the image is fading.
- If direct sunlight or strong artificial light (halogen lamps, etc.) shines on the front screen of the product (if the product has touch function, it may cause of malfunction of touch.), install the product in the shady environments or in the opposite direction of the source of the sunshine or the artificial light.


Ambient temperature

- Install the product in the well-ventilated place with maintaining the ambient temperature of below 35° C (95° F).

3.2 Unpacking Process



The following images may differ from the actual items.
Before unpacking the box, refer to the diagram below.



3.3 Handling Guide

 The following images may differ from the actual items.


Holding a product

1. Right way

At least two persons are required to handle the product during transportation.


Two persons should hold the each left and right handle of the backside of the product with one hand of the each person and with the other hand, grip the bottom portion of the rear side of the product to move.

(The illustration below may differ from the actual items.)



2. Wrong way


Do not use or touch any part of the front screen of the product during transportation.



Putting a product


1. Right Way

Before putting the product on the floor, prepare flat and soft cushions. Place the product horizontally and slowly on the floor. If firstly laying the edge of the bezel of the product, the screen panel of the product may be fragile or damaged.



2. Wrong way

Put down carefully not to damage the outside of the product. If the corner part of the product is placed first, the bezel may be damaged easily.




3.4 Product Installation

When installing the product with wall mount, make the product installed by a well-trained technician. Please refer to the User Guide of Wall Mounting.

 The product has VESA standard of 400X400 MM for wall mounting, and of M8 (Maximum length 35mm) of the screws by size.


 **Warning:** We are not responsible for the product damage or personal injury caused by user's own installation.



3.5 Wall mounting Installation

Install the product only on the robust and vertical wall. When installing inside the wall or cabinet, install the product with the space behind between the product and the wall as the illustration below.


Ambient temperature is kept below 35 °C.



3.6 Remote Controller

Inserting batteries in the remote controller

- Press the tab on the battery case and open it.
- Insert the battery (1.5V AAA) into the battery case.
- Insert the battery case until clack sounds.



- When loading the battery, check if the polarity of the batteries is correct.
- If not using the remote controller for long time, remove the batteries to prevent damage caused by battery fluid leak.
- Don't expose the battery to direct sunlight or excessive heat such as a fire.

⚠ Notes on the remote controller

- If anything interrupts in front of IR receiver or between IR receiver and remote controller, the remote controller may not work.
- If the receiving distance of the remote controller becomes narrow or does not work, replace the battery with new one.
- In case of the product is exposed to direct sunlight or fluorescent light, it may not operate.

3.7 Setup

Turning on the power

1. Connect the power cable of the product into outlet with AC 100-240V 50 / 60Hz.
2. Turn on the main AC power switch.
3. If the power indicator is green, the screen turns on automatically.
4. If the power light is red not green, press the power key on the remote controller or operate to turn on the power.





Changing language of the menu

- The language of the menu is basically English as the default set.
- Users can select a language
- To change the menu language,
 1. Press the Menu button to go to the menu.
 2. Select the OSD from the main menu.
 3. Select the language of the OSD setup menu.
 4. Select the language you want to select, and then exit the menu.

4 Remote Control for 4K

4.1 RS-232C connection

There are 4 types of RS232. Please check your RS232 pinout as below.

RS232 Female pinout (1)		RS232 Male pinout (2)		RS232 Male pinout (3)			RS232 Male pinout (4)	
								
Pin	Function	Pin	Function	Pin	Pin	Function	Pin	Function
3	RXD	3	RXD	3	3	RXD	2	RXD
2	TXD	4	TXD	2	4	TXD	3	TXD
5	GRD	1	GRD	5	1	GRD	5	GRD

- RXD : Data input to the display. Connects to TxD on the Controller
- TXD : Data output from the display. Connects to RxD on the Controller.
- GRD : Connects to GND on the Controller

Communication Parameter

Baud Rate	9600
Data Length	8 bit
Parity Bit	None
Stop Bit	1 bit
Hardware Handshake	Not supported
Authentication	None

Serial Command List

Description	Command	Value	Reply
Power Key Off	CMD_POWER_ON	69 D7 BF	
Power Key On	CMD_POWER_OFF	69 10 86	
Source change to HDMI1	CMD_SOURCE_HDMI1	69 CA CC	
Source change to HDMI2	CMD_SOURCE_HDMI2	69 C9 CD	
Source change to HDMI3	CMD_SOURCE_HDMI3	69 C8 CE	
Source change to HDMI4	CMD_SOURCE_HDMI4	69 B1 E5	
Source change to D-SUB	CMD_SOURCE_VGA	69 CB CB	
Source change to Component	CMD_SOURCE_YPbPr	69 C4 D2	
Source change to USB	CMD_SOURCE_USB	69 2A 6C	
Volume Up	CMD_VOL_INC	69 83 13	
Volume Down	CMD_VOL_DEC	69 86 10	

OSD Menu	CMD_KEY_MENU	69 8A 0C	
Key Up	CMD_KEY_UP	69 92 04	
Key Down	CMD_KEY_DOWN	69 D8 BE	
Key OK	CMD_KEY_OK	69 9B FB	
Key Left	CMD_KEY_LEFT	69 97 FF	
Key Right	CMD_KEY_RIGHT	69 9F F7	
Key Prev.	CMD_KEY_PREV	69 8F 07	
Key Rew	CMD_KEY_REW	69 D1 C5	
Key FF	CMD_KEY_FF	69 D0 C6	
Key Next	CMD_KEY_NEXT	69 93 03	
Key Play	CMD_KEY_PLAY	69 D2 C4	
Key Stop	CMD_KEY_STOP	69 8B 0B	
Key Freeze	CMD_KEY_FREEZE	69 B8 DE	
Key Mute	CMD_KEY_MUTE	69 DF B7	
Key Exit	CMD_KEY_EXIT	69 D4 C2	

5 Connect the external device

5.1 HDMI Connection


- HDMI input is recommended because it receives a digital signal input from an external device with HDMI output to ensure high quality of digital signal.

* Use the cable provided with the product. Otherwise, no image may be shown on the screen or normal display may not be shown.

- If connecting the product to the PC, it supports the VESA Display Data Channel (DDC) standard. This standard supports "plug and play" function which helps the PC recognize the product automatically to output the optimal resolution.

In order to operate the 'plug and play' after connecting the product, connect the video cable of the PC to the product before turning on your PC, and turn on the power of this product first and then turn on the power of the PC.

- When the incompatible resolution of the input signal is input to the product no image is shown on the screen or normal display is not shown. As for the supported resolutions, refer to page 31.



 If you receive a 3840 x 2160 60Hz input HDMI cable, please use the 4K,2K certified products. The screen may look strange.


5.2 VGA Connection

- To see the video, connect D-Sub 15P cable of the PC to the VGA In port of the product.

- If connecting the product to the PC, it supports the VESA Display Data Channel (DDC) standard. This standard supports "plug and play" function which helps the PC recognize the product automatically to output the optimal resolution.

In order to operate the 'plug and play' after connecting the product, connect the video cable of the PC to the product before turning on your PC, and turn on the power of this product first and then turn on the power of the PC.

- When the incompatible resolution of the input signal is input to the product no image is shown on the screen or normal display is not shown. As for the supported resolutions, refer to page 31.



6 Touch Requirements

6.1 Touch Requirements

Computer Configuration (Recommended):

- 3.0 GHz quad-core processor
- 8 GB RAM
- 10 GB available hard disk space
- 1 GB NVidia GTX330 graphics card


OS Compatibility

Operating System	Release Name	Version	Touch Sensor	T3kCfg program	Misc
Linux	Ubuntu	under 10.10	X	X	
		11.04	O	O	
		11.10	O	O	
		12.04.1	O	O	
		12.10	O	O	
		13.04	O	O	Multi-touch Digitizer support
		13.10	O	O	Multi-touch
		14.04	O	O	Multi-touch
		14.10	O	O	Multi-touch
Mac OS X	under Leopard	10.5.8	X	X	
	Lion	10.7	O	O	wheel inverted
	Mountain Lion	10.8	O	O	wheel inverted
	Mavericks	10.9	O	O	wheel inverted
	Yosemite	10.10	O	O	wheel inverted (T3k 2.8f is recommended)
Windows	XP	SP2	O	O	
		SP3	O	O	
	Vista		O	O	
	7	Basic or Lower	O	O	Mouse Only
		Home Premium or higher	O	O	Multi-touch Digitizer support
		OEM	O	O	Mouse Only
	8.1	PRO	O	O	Multi-touch Digitizer support
		RT	X	X	
10	PRO	O	O	Multi-touch Digitizer support	
	RT	X	X		
Android	under Honeycomb		X	X	
	Ice Cream Sandwich		O	X	Kernel Driver needed (Kernel 3.0.5 or above)
	Jelly Bean		O	X	Kernel Driver needed (Kernel 3.0.5 or above)
	KitKat		O	TBD	kernel 3.8 or above, Driver is not needed

7 Menu Control

7.1 Input selection

Press the Input button and then select **AV**, **Component**, or the input you want to select, and then press the **▶ (+)** button.



Input	Description
AV	AV input
Component	Component input
HDMI1	HDMI1 input
HDMI2	HDMI2 input
HDMI3	HDMI3 input
VGA	VGA input
USB	USB input

7.2 User function

Upper	Lower	Value	Note	
Picture	Picture mode	Standard, Dynamic, Mild, User	(Default: USER)	
	Contrast	0-100	(Default: 50)	
	Brightness	0-100	(Default: 55)	
	Color	0-100	(Default: 48)	
	Tint	0	(Default: 0)	
	Sharpness	0-100	(Default: 50)	
	Color Temp	Normal, Warm, Cool	(Default: Normal)	
	MEMC	Off, Low, Normal, High	(Default: Off)	
AUDIO	Sound Mode	Music, Movie, User, Flat	(Default: Music)	
	Bass	0-100	(Default: 70)	
	Treble	0-100	(Default: 80)	
	Balance	-50 - +50	(Default: 0)	
	Surround	On, Off	(Default: Off)	
	SPDIF Type	Off, PCM, RAW	(Default: RAW)	
Time	Sleep Timer	Off, 5, 10, 15, 30, 45, 60, 90, 120, 180, 240Min	(Default: Off)	
	No signal Auto power off	On, Back Light, off	Default: On)	
SETUP	Menu Language	English, Francais, Espanol	(Default: English)	
	Transparency	Off, On	(Default: Off)	
	Zoom mode	Just scan	(Default: Just scan)	
	Noise	Middle	(Default: Middle)	
	PC Setup			
	DLC	On, Off	(Default: Off)	
	HDMI Setting	HDMI1	1.4, 2.0	2.0
		HDMI2	1.4, 2.0	2.0
		HDMI3	1.4, 2.0	2.0
Restor Default	Yes, No	No		
Lock	Change Password	Change password, Confirm password		
	System Lock	On, Off	(Default: Off)	
	Input Lock	AV	UNLOCK, LOCK	(Default: UNLOCK)
		Component	UNLOCK, LOCK	(Default: UNLOCK)
		HDMI1	UNLOCK, LOCK	(Default: UNLOCK)
		HDMI2	UNLOCK, LOCK	(Default: UNLOCK)
		HDMI 3	UNLOCK, LOCK	(Default: UNLOCK)
VGA	UNLOCK, LOCK	(Default: UNLOCK)		
CHANNEL				

8 Trouble Shooting

The table below provides some general guidelines for trouble shooting problems you may encounter with your product. If the suggested solutions fail to resolve the problem or if you encounter an issue not described here, please contact your dealer or service centre.

Symptom	Checklist & Solution
The power is not turned on. (When the LED light indication is red or orange.)	<ul style="list-style-type: none"> • Turn on power switch of the product or by using remote controller, check if the product is in power saving mode for no input of video signal.
The power is not turned on. (LED indication that the light is off)	<ul style="list-style-type: none"> • Ensure that the product is plugged in and that the AC outlet is active. • Set the main power switch to the on position. • Try to connect other electric equipment to AC outlet to check if there is no problem in power source.
The remote controller does not work.	<ul style="list-style-type: none"> • Replace the batteries in the remote controller. • If the remote controller receiver of the product is prevented by any object, delete the object and try to operate again. • If the remote controller receiver of the product is exposed to direct sunlight or strong light, try to block the light and operate again. • Check the control buttons (OSD buttons) work properly.
The power is on only but the screen does not appear.	<p>When the LED indicator of the product is green, video displays on the screen. Turn on the power of the product by using the power switch or remote controller.</p> <ul style="list-style-type: none"> • Turn off the AC power, and then turn it on again.
A message of 'Input out of range' is displayed.	<ul style="list-style-type: none"> • Check if a signal with other resolution which the product does not support is input to the product and refer to the details in the page 31.
Images are not displayed correctly or noise is shown on the screen.	<ul style="list-style-type: none"> • Ensure the cables are connected in and video signal is active. • Change the cable. • Check if a signal with other resolution which the product does not support is input to the product and refer to the details in the page 31. • Connect another product to check if there is no problem, considering the possibility of problem in outer video signal equipment. • Ensure the input windows resolution and ratio(16:9) • When mirroring or duplicate displays can only be as high as the device screen will go. Hold Windows key and press P to Display only

'No Signal' message is displayed.	<ul style="list-style-type: none"> • Check to see if the external signal device is turned on. • Check if computer is on power saving mode by handling the mouse or pressing keyboard to wake. • Check to see if the external signal devices and cables are connected. • Check to see if the cable connections are loose or missing out. • Try changing the cable. • Check if the input selection of products is correctly set to an external device by using the SOURCE button on the remote controller.
HDMI screen is not displayed. Or screen appears strange.	<ul style="list-style-type: none"> • Check to see if the cable connections are loose or missing out. • Try changing the cable. • If you use an HDMI cable not certified, it may result in a problem.
HDMI display is small or large visible.	<ul style="list-style-type: none"> • Try adjusting video output size of the graphic card in case of computer.
The color of VGA screen is strange.	<ul style="list-style-type: none"> • Check to see if the cable connections are loose or missing out. • Try changing the cable. • Connect another product to check if there is no problem, considering the possibility of problem in outer video signal equipment.
The position of VGA screen is strange.	<ul style="list-style-type: none"> • Try adjusting the automatic position by using the menu on the remote controller.
The screen is too bright and the image is not separated.	<ul style="list-style-type: none"> • From the menu, try making the value of the black level lower on the screen menu setting. • Or try to initialize the screen menu settings.
The dark area of the screen is too bright	<ul style="list-style-type: none"> • From the menu, try making the value of the contrast lower on the screen menu settings. • Or try to initialize the PICTURE settings.
Screen looks too dark.	<ul style="list-style-type: none"> • Try to initialize the PICTURE settings.
Touch screen doesn't work	<ul style="list-style-type: none"> • See Connecting the Touch Screen Controller Host Computer to the Display
Touch Alignment	<ul style="list-style-type: none"> • Ensure the output resolution of the attached device is set to a 16:9 • Using T3k software(touch setting program) check the alignment of the cameras
No Sound on VGA	<ul style="list-style-type: none"> • Install into the "Sound" socket
No Sound on internal speaker	<ul style="list-style-type: none"> • Increase the volume level on both the Vidistri Europe BV interactive display, Media Player and Device e.g laptop or PC
No Sound on External Speakers	<ul style="list-style-type: none"> • Ensure the external speakers are connected to the correct jacks. • Check for any shorts on the wires connecting to the speakers.

	<ul style="list-style-type: none"> • Power down the touchscreen, remove any external speaker connection, wait for 30seconds, reapply power and test internal speakers only.
UD@60Hz is not displayed.	<ul style="list-style-type: none"> • Connect directly from HDMI 2.0 of PC to HDMI port of the screen. Screen has to be set HDMI 2.0 in OSD setting menu. • Use the bellow's gender of DP and HDMI port if your computer has only DP port for UD@60Hz. -Nextlink-MDPHC220
What kind of computer or specification do I need for 4K@60Hz?	<ul style="list-style-type: none"> • Video output must be 4K@60Hz • Memory and graphic card: 8GB above and NVIDIA® GeForce® GTX 745 (included 4GB DDR3) • • HDD : 1TB(64MB cash)7200RPM SATA 6Gb/S • Same or above specification (※ e.g Gamming desktop is normally suitable for this specifications : Dell Alienware X51 series)

9 Product Specification



Product specifications can be changed for quality improvement without prior notice.

Product	Vidi-Touch Navigator 65"LED
Dimensions (±5mm)	1750 (W) x 954 (H) x 93 (D)
Weight	78
Supported OS	Windows and Mac (driverless and calibration free) Linux, Android
Touch Screen	70"
LED Area	65"
Finish	Aluminum, Anodized
Resolution	UD 3840x2160 @60Hz
Touch tool	Fingertips or any tips, Multi-touch-supports 10 touch points (4-standard)
Touch point speed & accuracy (mm)	< 7ms & ±3mm
Integrated Speakers	15Wx2
Amplified Speaker Out	15Wx2
Input/ Output	AC 100-240V 50/60Hz, Earphone, S/PDIF, Component(Y/PB/PR), AV(CVBS/L/R), Sound, D-SUB, USB for service, HDMI(3), RS232, Speaker out, USB for touch(Laptop, PC), Fan on/off
Mount	VESA
Switch	FAN ON/OFF (Internal cooling fan on both sides)
Packing Dimensions (mm)	1945(W) x 1105(H) x 325(D)
Packed Weight (Kg)	90
Accessories	1xHDMI cable, 1 x USB cable, 1 x USB extender, 1 x stylus pen,1 x cleaning cloth

10 Supported Resolutions

Video Input	AV	Video system	PAL/NTSC
		Video Level	1.0Vp-p±5%
	Component	480i, 480p, 576i, 576p, 720p, 1080i, 1080p	
	HDMI	480i, 480p, 576i, 576p, 720p, 1080i, 1080p, 4K 30Hz, 4K 60Hz	

11 Required information

11.1 Prevent image sticking

⚠ The fixed image (title, menu image, picture, motionless movie etc.) on the screen is maintained for a long time, image sticking may occur. Image sticking may be subject to operating time of still picture. Since the image sticking is not defect but a characteristic of the product, it is restricted from the product warranty.

Thus, please refer to the following information for the prevention of image sticking.

- When external device (PC) is not used for a long time, please use screensavers.
(The screensaver should be monochrome or moving image.)
- If 4:3 aspect ratio is used for a long time, image sticking might occur.
So, it is recommended to use the full screen.
- In case of displaying still picture for long time, change pictures a certain time.

If image sticking is shown, turn off the unit for a while and turn it on again.
Turn off time may be require